## **Programming Quick Reference**

The following procedures should be performed from the normal weigh mode screen. Some procedures require a password.

**Create a New PLU** There are several fields that may be programmed for each PLU. The number of fields is affected by the Type of PLU you select and the settings in Menu S0 PLU Fields Visible. This example represents the fields that will be available on a new DLP-300 right out of the box.

## Ex.: Weigh Mode PLU

Press MODE key twice. Press the Print key. Enter the PLU Number (1-999999) you wish to create and press the PRINT key. Enter the PLU Name and press the PRINT key. (To use multiple lines of PLU Name press the X key to go to the next line. Keep in mind that the font size may limit the number of characters actually printed on the label.) Enter the Unit Price and press the PRINT key. Enter the PLU Type (0 for Weight or 1 for Non-Weight or 2 for By Count.) This example is for a Weigh Mode PLU so enter a 0 and press the PRINT key. Enter the Item Code (1-999999) and press the PRINT key. Enter the Sell By Date (1-9999) and press the PRINT key. Enter the Tare Weight and press the PRINT key. Enter the Quantity (1-99) and press the PRINT key. Enter the Ingredient message and press the PRINT key. Enter the Print Sell By Date Status. (0 = Don't Print/1 = Print) and press the PRINT key. Enter the Print Sell By Time Status. (0 = Don't Print/1 = Print) and press the PRINT key. Enter the Print Pack Date Status. (0 = Don't Print/1 = Print) and press the PRINT key. Enter the Discount Status. (0 = Don't Print/1 = Print) and press the PRINT key. Enter the Discount Status. (0 = Don't Print/1 = Print) and press the PRINT key. Enter the Discount Status. (0 = Don't Print/1 = Print)

**Deleting a PLU** To Delete an existing PLU press the MODE key twice. Press the PRINT key. Enter the PLU Number that you want to delete and press the VOID key.

**Speed Keys** Press the MODE key twice. Press the X key four times. Press the PRINT key. Press the Speed Key that you want to program. Enter the PLU Number you want to assign to that key. Press the SAVE key. Press the FEED/ESC key.

**Speed Keys using Multiple Levels** Press the MODE key twice. Press the X key four times. Press the PRINT key. Press the Speed Key that you want to program. Enter the PLU Number you want to assign to that key. Press the SAVE key. Press the PRINT key. Press the same Speed Key again. Enter the PLU Number you want to assign to that key on Level 2. Press the SAVE key. Press the PRINT key. Press the same Speed Key again. Enter the PLU Number you want to assign to that key on Level 3. Press the SAVE key. Press the FEED/ESC key.

**Date & Time** Press the MODE key twice. Press the X key seven times. Press the PRINT key. Enter the current Date in the correct format (MMDDYY) and press the PRINT key. Enter the current Time (HHMMSS) and press the PRINT key. Press the SAVE key.

**Shop Name and Address** Press MODE key twice. Press the X key. Press the PRINT key. Enter the Shop Number (1 - 32) and press the PRINT key. Enter the Shop Name and press the PRINT key. Press the SAVE key.