



Calibration Instructions

For Scale Technicians Only

Model SEK

- 1- Press ON/ZERO to turn on the scale. Before the countdown from 9 to 0 finishes press and hold MODE/RANGE key.
- 2- The display will show "CAL.?_1"
- 3- Press MODE/RANGE.
- 4- The display will show "YES". The platter should be free from any loads to calibrate the zero point.
- 5- After zero point is calibrated, the display will show "LOAD" "XXXX.X" "or" "XXXX.X"
- 6- Place the weight marker with the corresponding weight shown on the display. After calibration is finished, the display will show "CAL.?_2"
- 7- Press ON/ZERO to exit calibration and return to normal weighing mode. If there is a need to calibrate the second point, repeat instructions from number 3 to 6.
- 8- After the second point is calibrated, the scale will automatically return to weighing mode.