



# MOBILE AND PORTABLE LIVESTOCK SCALES



- ★ Completely Self-Contained NTEP Legal-for-Trade Mobile Animal Weighing
- ★ Mobile Scales with Wheels and Also Portable Scales with Lower Frame for Transport
- ★ Includes Weight Indicator, Ticket Printer, and Battery

  (Battery not included on standard LSP models)
- ★ Weigh Groups of Cattle up to 15-20 Head at a Time (20,000-lb Capacity)
- ★ X-Lug Rubber Livestock Flooring Included Standard for Livestock Stability and Assurance
- ★ Scales Come Fully Assembled







## CARDINAL SCALE'S **MOBILE WEIGHING** CENTER:

- ★ Calculates Shrink Loss for Livestock Group
- Displays Current Head Count, Gross Weight, and Average Weight
- ★ Also Displays Previous and Total Head Count, Gross Weight, and Average Weight
- Displays Transaction Number and Transaction Shrinkage
- Printable Report Summarizing Above Information per Transaction
- Inclinometer Detects Scale Angle to Determine if Angle is Out of Acceptable Tolerance for Weighing
- Weight Indicator Displays Current Tilt Angle (blanks out if out of NTEP tolerance)
- **Comes With USB Port to Store Transactions** on Portable USB Drive
- Transactions Stored on USB Drive May Be Summarized for Printing

## **USER FRIENDLY OPERATION**

Lowering the scale into weighing mode after transport is easy and can be quickly done by one person. For the mobile models, pull the safety locking pins for transport mode, pull the pin on the tongue to split apart the two arms on the front of the scale, turn the air purge valve to release the air from the airbags and lower the scale, and then rotate the weighbridge lifting handle inward at each corner.

[naņs] Shrink 2.50%


3 600 200 Last : 2 Gross: 400 Avg : 200 Current: Gross

Gross: 1250 Avg : 208

Total:6

SHRINK WEIGH FINISH REPRINT

Livestock weighing transaction results are all displayed on the easy-to-read, transflective LCD screen that remains highly visible, even in direct sunlight.



Cardinal Scale's weight indicators feature StableSENSE® digital filtering that filters the weight signal to produce a stable weight display in spite of motion on the scale platform due to animal movement.

The Weight Wrangler's mobile weighing center includes an inclinometer that eliminates the need to recalibrate the scale after transport. The self-contained scale provides legal-for-trade weights in multiple locations with up to a 5% tilt angle (maximum allowed by NTEP) in any direction.












13' L x 7' 4" W x 8' 2" H 15,000 lb x 5 lb Lower Frame

PORTABLE



18' 5" L x 7' 4" W x 8' 2" H (not including tongue) 20,000 lb x 5 lb Tandem Axle

#### LSP2018-MWC225P



Each Weight Wrangler model listed here includes weight indicator and ticket printer

### **OPTIONAL:**

Collector Panel Mount Bow (qty. 1) Horse Risers **Dual Latch Gate** Solar Panel