

FLOOR SCALE ACCESSORY · BUMPER GUARD

OP-433 Bumper Guard

High-visibility bumper protection for floor scales in forklift and heavy-traffic environments



WHY CHOOSE THE OP-433

- ✓ **Prevents Forklift Damage** to your floor scale investment
- ✓ **High-Visibility**, easy to see in almost any environment
- ✓ **Fast Installation** with included anchor-bolt hardware
- ✓ **For OP-916 Series Floor Scales**, drop-in fit
- ✓ **Three Bumper Lengths**, 3', 4', and 5' options
- ✓ **Sold in Packs of 1, 2, 3, or 4** to fit any deck size

Floor scales take a beating in busy warehouses. A single forklift strike can bend a deck, damage a load cell, and take your scale offline for days. The OP-433 Bumper Guard is a dedicated, high-visibility barrier that surrounds your scale platform and absorbs impact before it reaches the deck. Anchor-mounted directly to the concrete floor around the OP-916 series footprint, the OP-433 keeps forklift wheels and other hazards from ever touching the platform edges. Easy to spot in low light, easy to install, and built to protect the scale you already paid for.

FEATURES

- ✓ Easy to see in almost any environment
- ✓ Prevents forklifts or other hazards from damaging the scale
- ✓ Easy to install with 4.5", 1/2" anchor bolts and 5/8" washers
- ✓ For use with OP-916 series floor scales
- ✓ Available in 3-foot, 4-foot, and 5-foot lengths
- ✓ Configure sets of 1, 2, 3, or 4 bumpers per order

CONFIGURATION OPTIONS

Model	OP-433
Compatibility	OP-916 series floor scales
Bumper Lengths	3', 4', 5'
Pack Sizes	1, 2, 3, or 4 bumpers
Anchor Bolts	4.5", 1/2" diameter
Washers	5/8"
Category	Floor Scale Accessory

INSTALLATION

Position bumpers around the perimeter of your OP-916 series floor scale, mark the anchor points, and secure each bumper to the concrete slab using the 4.5-inch, 1/2-inch anchor bolts and 5/8-inch washers noted above. No electrical work, no scale downtime.

Contact us to order the right OP-433 configuration 800-917-7205 · sales@primeusascales.com